



1
USING TIP OF BULLET, FLAT HEAD SCREWDRIVER, OR FINGERNAIL, UNLOCK THE SECURING TABS ON EITHER SIDE OF THE MARCO HR RAM.



2
SWING RAM DOWN INTO LOADING POSITION EXPOSING THE LOADING PORT ON THE SIDE.



3
SLIDE ONE CHEMLIGHT AT A TIME THROUGH THE LOADING PORT AND INTO POSITION. USE YOUR THUMB OR INDEX FINGER TO CAREFULLY DEPRESS THE STACK OF LIGHTS AND REPEAT UNTIL FULLY LOADED.



4
CLOSE RAM UNTIL BOTH SIDES SNAP BACK INTO PLACE. SQUEEZE DEVICE WITH FINGERS ON THE RAM AND PALM OF HAND ON THE PALM SHELF TO CRACK AND DISPENSE LIGHTS.

